

LJ Industrie


Location - Vente
Positionnement - Soudage

Groupe H.T.P.

T 33 (0) 4 76 98 36 09
F 33 (0)4 76 98 41 57
lji@lambert-jouty.com

* Rental Equipments *

Type	Designation	Load Capacity	Identification
Rotator	CZ-25	25t	3 & 4
Rotator	CZ-25	25t	160 & 161
Rotator	CZ-40	40t	12 & 168
Rotator	CZ-40	40t	162 & 163
Rotator	CZ-60	60t	64 & 132
Rotator	CZ-60	60t	72 & 97
Rotator	CZ-100	100t	78 & 137
Rotator	CZ-160	160t	171 & 172
Rotator	CZ-250	250t	169 & 170
Positioner	P 82-09 V	650 kg at 100 mm	174
Positioner	P-H5 V	16 t at 175 mm	173



LJ Industrie

Location - Vente
Positionnement - Soudage

Groupe H.T.P.

T 33 (0) 4 76 98 36 09

F 33 (0)4 76 98 41 57

lji@lambert-jouty.com

* Rental Conditions *

- ✓ Minimum renting : 4 weeks according to indicated price.
- ✓ Payment of the first term by cheque when you receive the order.
- ✓ Additional week of renting according to indicated price.
- ✓ Payment of additional weeks of renting by monthly bill.
- ✓ Renting period includes the first day of disposal and the day of return in our workshop.
- ✓ Every started week of renting must be completely paid.
- ✓ Transport (departure and return) must be organized by people who rent.
- ✓ People who rent are responsible for the material from picking up until return in our workshop.
- ✓ Repairing of material following production hitch is at the charge of the people who rent.
- ✓ Disposal of the material is linked to availability at requested date.
- ✓ Shipping of equipment is allowed only when rental contract is back, signed by the authorized people.
- ✓ In case of an order, please specify renting time.
- ✓ Power supply of all our equipments is 400V/3/50-60Hz.